**1 Anslutningssladd MS**

Liitintäjohto / Connecting cable / Anschlusskabel

2 Intagskabel MK

Elementikaapeli / Inlet cable / Einbaukabel

3 Batteriladdare BL

Akkuvaraaja / Battery Charger / Batterielader

4 Relä till timer

Rele ajastimelle / Relay for the timer / Timerrelais

5 Skarvkabel

Jatkokaapeli / Extension cable / Verlängerungskabel

6 Grenuttag

Haaroituspistorasia / Multiple socket / Verteilerstück

7 Motorvärmare

Vastusosa / Engine heater / Motorvorwärmere

8 Kupévägguttag

Sisätillapistorasia / Cab wall socket / Heizlüfter-Steckdose

9 Kupévärmare

Tehokasta lämpöä / Cab heater / Heizlüfter

10 Fjärrkontroll till timer

Kaukosäädin ajastimelle / Remote for the timer / Fernsteuerung für den Timer

11 Strålningsskydd

Lämpöeriste / Heat Shield / Hitzeschutz

12 Pump

Pumppu / Pump / Pumpe

Low Voltage Directive, 73/23/EEC, the EMC Directive, 89/336/EEC, including amendments by the CE marking Directive, 93/68/EEC

Product

Engine preheater	MVP...
Inlet cable	MK
Mains supply cable	MS

The following harmonised European standards or technical specifications have been applied:

Standards	Test reports issued by	Regarding
SS 433 07 90	SEMKO	electrical safety
EN 60 335-1	SEMKO	electrical safety
EN 60309-1/ 2 (1992)	SEMKO	electrical safety
CENELEC HD 22	SEMKO	electrical safety
CEE 7	SEMKO	electrical safety
EN 50 081-1 (1992)	SEMKO	EMC-emission
EN 50 082 (1995)	SEMKO	EMC-immunity

- The products comply with the LV safety standards as per above.

We have an internal production control system that ensures compliance between the manufactured products and the technical documentation.

- The products comply with the harmonised EMC standards as per above.

The products is CE marked in -96.

As manufacturer, we declare under our sole responsibility that the equipment follows the provisions of the Directives stated above.

Eskilstuna, January, 2011

Peter Gillbrand, President

Calix AB
PO-Box 5026
SE-630 05 Eskilstuna
Sweden

Phone: +46 (0)16-10 80 00
Support: +46 (0)16-10 80 90
Fax: +46 (0)16-10 80 60

E-mail: info@calix.se
E-mail: teknik@calix.se
Internet: www.calix.se

MONTERINGSANVISNING ASENNUSOHJEET ASSEMBLY INSTRUCTIONS EINBAUHINWEISE

M84



Observera att den avbildade motorvärmaren inte behöver vara identisk med den faktiska motorvärmaren.

Note that the illustrated heater must not be identical to the actual heater.

Huom! Kuvassa oleva lämmitin ei tarvitse olla identinen tosiasiallisesta lämmittimen kanssa.

Bitte beachten Sie, der dargestellte Vorwärmer muss nicht dem tatsächlichen Vorwärmer entsprechen.

1. Tappa ur kylvätskan.
2. Motorvärmaren monteras på slangen mellan den befintliga cirkulationspumpen och stosen på nedre kylarslangen.
3. Demontera slangen från nedre kylarslangens anslutningsstos. Montera de medförförda slangarna och värmaren enligt bilden. Se till att slangklämmorna kommer helt innanför upphöjningarna på värmarens anslutningsrör.
4. Fyll på kylvätska och lufta ur kylsystemet. Se instruktionsboken. Kör motorn och kontrollera att inget läckage förekommer.

SUOMI


1. Poista jäähdytysneste.
2. Moottorilämmittin asennetaan letkuun kiertovesi pumpun ja moottorilohkon väliin.
3. Irrota jäähdyttimen alavesiletkulitot. Asenna mukaan tulleet letkut ja lämmittimen kuvanmukaisesti. Varmista että letkuklemmarit tulevat kokonaan lämmittimen liitosputkien korotuksien sisäpuolelle.
4. Täytä jäähdytysjärjestelmä ja suorita ilmaus käyttöohjekirjan mukaisesti. Käynnistä moottori ja tarkista mahdolliset vuodot.

ENGLISH

1. Drain the coolant.
2. Install the engine heater on the hose between the existing circulation pump and the connection sleeve on the lower cooling hose.
3. Disconnect the hose from the connecting sleeve on the lower cooling hose. Install the supplied hoses and the heater as shown in the picture. Make sure that the hose clamps end up completely inside of the raised parts on the heater's connecting pipe.
4. Fill coolant and bleed all air from the cooling system. See instruction manual. Run the engine and check to make sure that there are no leaks.

DEUTSCH

1. Kühlwasser ablassen.
2. Installieren Sie das Heizelement im Schlauch zwischen der werksmäßigen Umwälzpumpe und dem Motorblock.
3. Trennen Sie den Schlauch vom Anschlußstutzen des unteren Küllerrohrs. Installieren Sie den mitgelieferten Schlauch und das Heizelement wie abgebildet. Achten Sie darauf, dass die Schlauchschellen komplett innerhalb der Erhöhung der Anschlussstutzen des Heizelements liegen.
4. Kühlwasser füllen und Kühlungssystem lüften. Hinweise der Kfz-Betriebsanleitung beachten. Motor laufen lassen und Einbaustelle auf Dichtigkeit prüfen.

**MERCEDES**

- C 180 CDI (Without start/stop) 2009--> OM651
 C 200 CDI (Without start/stop) 2009--> OM651
 C 220 CDI (Without start/stop) 2009--> OM651
 C 250 CDI (Without start/stop) 2009--> OM651
 E 200 CDI (Without start/stop) 2009--> OM651
 E 220 CDI (Without start/stop) 2009--> OM651
 E 250 CDI (Without start/stop) 2009--> OM651
 GLK 220 CDI (Without start/stop) 2009--> OM651
 GLK 250 CDI (Without start/stop) 2010--> OM651



= Motortyp
 = Moottorityyppi
 = Engine model